Mfr & service For: Embedded, Medical, Textile & Agri Electronics

ardware Development - Design & Troubleshooting remained to the provided for the provided fo

Our Products:
Neuron Patient's & Multipurpose Monitor
Neuron Spot Locator
Neuron Multipurpose Mobile Starter
Neuron Multipurpose Mobile Starter
Neuron Wireless Water Level Controller
Neuron Temperature with Humidity
Monitor & Controller

neurongsm@gmail.com

All our Products are controlled by Mobile Phone anywhere in the world We can do any electronic products as per customer requirement

purchase@neurongsm.com

NEURON VEHICLE SPOT LOCATOR

How to give Commands (messages) to operate our Spot Locator

| S.No | FEATURE | Send Message as [Commands can be either in Capital or Small letters without space] |
|------|---|--|
| 1 | To get the Location details of your Vehicle. | Loc |
| 2 | To set T ime & D ate of your unit. (Real Time Clock). | SMS Format: Td (Hour)(Minute)(AM or PM)(Date)(Month)(Year) Ex: Td1230A201115 (To set the time 12:30AM and date 20.11.15) Date Month How to Set? Td1230A201115 Year Hour, Min, A for AM or P for PM |
| 3 | To ON the Auto Frequent Timer Option. | SMS Format: Ton(Hour)(Minute) Ex: Ton0130 To get location details for every 1 hour 30 minutes. How to set? Ton0130 V Hour Min |
| 4 | To set Over speed Value | SMS Format: Oss(speed) Ex: Oss090 To set Over Speed as 90 km/hour |
| 5 | To OFF the Auto Frequent Timer Option. | Toff |
| 6 | To Know your Vehicle Speed | Spd |
| 7 | To Know your Vehicle Over Speed set value and Auto Frequent Time Interval | Set |
| 8 | To Know Pre Fixed Time and Location | SS |
| 9 | To Know your Vehicle Total Running Time Today | Trt |

NEURON GSM TECHNOLOGIES

18, Municipal Office Road, Opp. ATSC Theatre, Pollachi-642001 9150651606, 8925763612

Email-id: <u>neurongsm@gmail.com</u>, Website: <u>www.neurongsm.com</u>

We Make Things That Make India Proud